

## **LIGHT LIMITERS**


www.tal-usa.com/ 1-877-902-5588 7:30am-3:30pm PT

Visit www.tal-usa.com/replacement for diagrams and other resources


## 3-Wire Limiter

- 1. Turn off power at the breaker. \*\*
- 2. Locate the limiter (usually found in the switch housing, light kit, or on top of the motor).
- 3. Remove the crimps holding the limiter's red, white, and blue wires.

## Use this diagram to bypass the limiter and test the light.




Use this diagram to install a new limiter.




## 2-Wire Limiter

- 1. Turn off power at the breaker. \*\*
- 2. Locate the limiter (usually found in the switch housing, light kit, or on top of the motor).
- 3. Remove the crimps holding the limiter's blue wires.

Use this diagram to bypass the limiter and test the light.





Warning: Risk of Electric Shock. Damaged parts may discharge; handle with care or contact an electrician.